

Specification	Color	Yield	Description	
HP Toner Chips				
CE255A	BK	6K	HP LaserJet P3015	16, 20
CE255X	BK	12.5K	HP LaserJet P3015	16, 20
CE278A/CE285A Universal	BK	#	HP LaserJet P1560/P1566/P1600/P1606/P1100/P1102W/M1130/M1210	43, 20
CE278A	BK	2.1K	HP LaserJet P1560/P1566/P1600/P1606	16, 20
CE285A	BK	1.6K	HP LaserJet P1100/P1102W/M1130/M1210	16, 20
CE505A	BK	2.3K	HP LaserJet2030/2035/2050/2055	16, 20
CE505X	BK	6.5K	HP LaserJet2030/2035/2050/2055	16, 20
CC364A	BK	10K	HP LaserJet4014/4015/4515	21, 60
CC364X	BK	24K	HP LaserJet4014/4015/4515	21, 60
CB436A/388A	BK	2k/1.5k	HP LaserJet P1007/1008/P1505/M1120/M1522	16, 20
CB436A/435A	BK	2k/1.5k	HP LaserJet P1005/1006/P1505/M1120/M1522	16, 20
Q7516A	BK	12K	HP LaserJet 5200/CANON LBP 3500	27, 00
Q7570A	BK	15K	HP LaserJet 5025/5035	162, 00
Q7553A	BK	3K	HP LaserJet P2015/2015d/2015n/2015dn	16, 20
Q7553X	BK	7K		16, 20
Q7551A	BK	6.5K	HP LaserJet P3005/P3005d/M3027/M3035	16, 20
Q7551X	BK	13K		16, 20
Q5949A	BK	2.5K	HP LaserJet 1160/3390/3392/1320/1320n	16, 20
Q5949X	BK	6K	HP LaserJet 1160/3390/3392/1320/1320n	16, 20
Q6511A	BK	6K	HP LaserJet 2410/2420/2430	16, 20
Q6511X	BK	12K		16, 20
Q1338A	BK	12K	HP LaserJet 4200/4200n/4200tn/4200dtn	16, 20
Q1339A	BK	18K	HP LaserJet 4300n /4300tn/4300dtn/4345mfp	16, 20
Q5942A	BK	10K	HP LaserJet 4250/4350/4350L	16, 20
Q5942X	BK	20K		16, 20
Q5945A	BK	18K	HP LaserJet 4345mfp	27, 00
C8061	BK	6K	HP LaserJet 4100/4100mfp)	63, 45
8061/8543 Universal	BK	6k/30k	HP LaserJet 4100/9000/9040/9050	81, 00
HP Universal A	BK	#	HP2014/2015/3005/3027/3035/1160/1300/1320/2300/2400/2410/2420/2430/4200/4250/4300/4350(A)	16, 20
HP Universal X	BK	#	HP2014/2015/3005/3027/3035/1160/1300/1320/2300/2400/2410/2420/2430/4200/4250/4300/4350(X)	16, 20
HP Color Toner Chips				
CE310A	BK	1. 2K	HP Color LaserJet 1025 NEW	81, 00
CE311A	C	1K		81, 00
CE312A	Y	1K		81, 00
CE313A	M	1K		81, 00
CE320A	BK	2K	HP Color LaserJet Pro CM1415fn, 1525 NEW	76, 95
CE321A	C	1. 3K	HP Color LaserJet Pro CM1415fn, CM1415fnw NEW	76, 95
CE322A	Y	1. 3K	HP Color LaserJet Pro CM1415fn, CM1415fnw NEW	76, 95
CE323A	M	1. 3K	HP Color LaserJet Pro CM1415fn, CM1415fnw NEW	76, 95
CE740A	BK	7K	HP Color LaserJet CP5220/5225/5225dn/CANON9100 NEW	87, 75
CE741A	C	7. 3K		
CE742A	Y	7. 3K		
CE743A	M	7. 3K		
CE260A	BK	17K	HP Color LaserJet CP4020/4025/4525/5020/5025 NEW	81, 00
CE261A	C	8. 5K		
CE262A	Y	8. 5K		
CE263A	M	8. 5K		
CE250A	BK	5K	HP Color LaserJet CP3525/CM3530 New!!	27, 00
CE250X	BK	10.5K		27, 00
CE251A	C	7K		27, 00
CE252A	Y	7K		27, 00
CE253A	M	7K		27, 00
CB380A	BK	16.5K		HP Color LaserJet 6015 toner chip New!!
CB381A	C	21K	81, 00	
CB382A	Y	21K	81, 00	
CB383A	M	21K	81, 00	

CB384A	BK	35K		81, 00
CB385A	C	35K	HP Color LaserJet 6015 Drum chip New!!	81, 00
CB386A	Y	35K		81, 00
CB387A	M	35K		81, 00
CC530A	BK	3.5K		HP Color LaserJet 2020/2025/CM2320 (OEM)
CC531A	C	2.8K	HP Color LaserJet 2020/2025/CM2320 (OEM)	13, 50
CC532A	Y	2.8K	HP Color LaserJet 2020/2025/CM2320 (OEM)	13, 50
CC533A	M	2.8K	HP Color LaserJet 2020/2025/CM2320 (OEM)	13, 50
CB540A	BK	2.2k	HP Color LaserJet 1215/1515/1518/1312(OEM)	13, 50
CB541A	C	1.4k	HP Color LaserJet 1215/1515/1518/1312(OEM)	13, 50
CB542A	Y	1.4k	HP Color LaserJet 1215/1515/1518/1312(OEM)	13, 50
CB543A	M	1.4k	HP Color LaserJet 1215/1515/1518/1312(OEM)	13, 50
CC530/540A	BK	3.5K	HP 2020/2025/2320/1215/1515/1518/1312 New!!	16, 20
CC531/541A	C	2.8K	HP 2020/2025/2320/1215/1515/1518/1312 New!!	16, 20
CC532/542A	Y	2.8K	HP 2020/2025/2320/1215/1515/1518/1312 New!!	16, 20
CC533/543A	M	2.8K	HP 2020/2025/2320/1215/1515/1518/1312 New!!	16, 20
2500K	BK	5K	HP Color LaserJet 1500/2500/2550/2550L/2550N/	27, 00
2500C	C/M/Y	4K		27, 00
Q3964A	Drum	20K	HP Color LaserJet 1500/2500/2550 Drum chip	32, 40
Q2670A	BK	6K	HP Color LaserJet 3500/3500n/3550	32, 40
Q2671A	C	4K		32, 40
Q2672A	Y	4K		32, 40
Q2673A	M	4K		32, 40
35/37	CMYK	#	HP Color LaserJet 3500/3500n/3550/3700/3700dn	63, 45
Q6000A	BK	2.5K	HP Color LaserJet 1600/2600/2605/1015/1017/CANON LBP 5000 (OEM)	24, 30
Q6001A	C	2K		24, 30
Q6002A	Y	2K		24, 30
Q6003A	M	2K		24, 30
Q6000A*	BK	#	HP Color LaserJet 1600/2600/2605/3000/3600/3800/2700/4700	24, 30
Q6001A*	C	#		24, 30
Q6002A*	Y	#		24, 30
Q6003A*	M	#		24, 30
Q7560A	BK	6.5K	HP Color LaserJet 2700/3000	27, 00
Q7561A	C	3.5K		27, 00
Q7562A	Y	3.5K		27, 00
Q7563A	M	3.5K		27, 00
Q6470A	BK	6K	HP Color LaserJet 3600/3800/CP3505	27, 00
Q6471A	C	4K	HP Color LaserJet 3600	27, 00
Q6472A	Y	4K		27, 00
Q6473A	M	4K		27, 00
Q7581A	C	6K	HP Color LaserJet 3800/CP3505	27, 00
Q7582A	Y	6K		27, 00
Q7583A	M	6K		27, 00
Q5950A	BK	11K	HP Color LaserJet 4700	27, 00
Q5951A	C	10K		27, 00
Q5952A	Y	10K		27, 00
Q5953A	M	10K		27, 00
Q6460A	BK	12K	HP Color LaserJet 4730	27, 00
Q6461A	C	12K		27, 00
Q6462A	Y	12K		27, 00
Q6463A	M	12K		27, 00
C9720A	BK	9K	HP LaserJet 4600/4650	54, 00
C9721A	C	8K		54, 00
C9722A	Y	8K		54, 00
C9723A	M	8K		54, 00
46/55	CMYK	#	HP LaserJet 4600/4650/5500/5550	81, 00
4500D	Drum	#	HP Color LaserJet 4500/4550/8500/8550 Drum chip	40, 50
CB400A	BK	7.5K	HP LaserJet 4005	121, 50
CB401A	C	7.5K		121, 50
CB402A	Y	7.5K		121, 50
CB403A	M	7.5K		121, 50

C8550A	BK	25K	HP 9500 toner chip	121, 50
C8551A	C	25K		121, 50
C8552A	Y	25K		121, 50
C8553A	M	25K		121, 50
C8560A	BK	40K	HP 9500 Drum chip	121, 50
C8561A	C	40K		121, 50
C8562A	Y	40K		121, 50
C8563A	M	40K		121, 50
Samsung Toner Chips				
D108S	BK	1.5K	Samsung ML-1640/1641/2240/2241/2245 (EXP/EURO) New!!	81, 00
D109S	BK	2.5K	Samsung SCX4300/4310/4315 (EXP/EURO) New!!!	157, 95
D208S	BK	4K/10K	Samsung ML-1635/ML-3475/SCX-5635/5835 (EXP/EURO) New!!	157, 95
D209S	BK	5K	Samsung SCX4824FN/4826FN/4828FN (EXP/EURO) New!!	157, 95
D308S	BK	10K/20K	Samsung ML-4055/4555 (EXP/EURO) New!!	157, 95
D106S	BK	2K	Samsung ML2245 (EXP/EURO) New!!	157, 95
D205	BK	10k	Samsung ML3310/3710/SCX4833/SCX5637/SCX5737	162, 00
D206S	BK	10K	Samsung SCX5935FN (EXP/EURO) New!!	157, 95
CLT407	BK	1.5K	Samsung CLP-320/325/CLX-3285 (EXP/EURO) New!!	157, 95
	CMY	1K		
CLT409	BK	1.5K	Samsung CLP310/315/CLX3170/CLX3175//3185 (EXP/EURO) New!!!	157, 95
	CMY	1K		166, 86
MLT104	BK	1.5K	Samsung ML-1660/1661/1665/1666/SCX3200/3205 (EXP/EURO) New!!	125, 55
MLT105	BK	2.5K	Samsung ML1911/1915/2525/SCX4600/4623/SF650/651 (EXP/EURO) New!!	157, 95
CLT 508	BK	2.5K/5K	Samsung CLP-615/620/670 (EXP/EURO) New!!	157, 95
	CMY	2K/4K		
CLT-609	CMYK	7K	Samsung CLP-770 (EXP/EURO) New!!	157, 95
ML-D2850DA	BK	2K	Samsung ML-2850D/2851ND (KOR, EXP, EUR)	32, 40
ML-D2850DB	BK	5K		32, 40
SCX-560R	BK	3K	Samsung SCX-560R/565P (KOR, EXP)	32, 40
ML-D3050DA	BK	4K	Samsung ML-3050/3051N/3051ND (KOR, EXP)	32, 40
ML-D3050DB	BK	8K		32, 40
ML-D1630DA	BK	2K	Samsung ML-1630/1631/SCX4500/4501 (KOR, EXP)	32, 40
ML-D3470DA	BK	4K	Samsung ML-3470D/3471ND (CHN, KOR, EXP)	32, 40
ML-D3470DB	BK	10K		32, 40
SCX-D4725DA	BK	3K	Samsung SCX-4725 (KOR, EXP)	32, 40
SCX-D4550DA	BK	10K	Samsung SCX-4550/4551/4050 (KOR, EXP)	32, 40
SCX-D5530DA	BK	4K	Samsung SCX-5530/5330N/5530FN (KOR, EXP)	32, 40
SCX-D5530DB	BK	8K		32, 40
SCX-6320	BK	8k	samsung 6320 (KOR, EXP)	32, 40
ML-2150DA	BK	8K	Samsung ML-2150/2550 (Universal)	13, 50
ML-2150DB	BK	10K		13, 50
ML-2250DA	BK	3K	SAMSUNG ML-2250/2250G/2251N/2252W/2251NP/2255G (KOR, EXP)	13, 50
ML-2250DB	BK	5K		13, 50
ML-3560DA	BK	6K	Samsung ML-3560/3561N (KOR, EXP)	13, 50
ML-3560DB	BK	12K		13, 50
SCX-4200D3	BK	3K	Samsung SCX-4200 (KOR, EXP)	13, 50
SCX-4720D3	BK	3K	Samsung SCX-4720FN/4520 (KOR, EXP)	13, 50
SCX-4720D5	BK	5K		13, 50
CLP-500	CMYK	#	Samsung CLP-500	8, 10
Samsung FUSE	#	#	Samsung 4216/4521/530/5100/808 EPSON1000/2000	6, 75
CLP-510D7K	BK	7K	Samsung CLP-510 (KOR, EXP)	32, 40
CLP-510D5C	C	5K		32, 40
CLP-510D5M	Y	5K		32, 40
CLP-510D5Y	M	5K		32, 40
CLP-K300A	BK	2K	Samsung CLP-300/300N/CLX-2160/3160N/3160FN (KOR, EUR, EXP)	13, 50
CLP-C300A	C	1K		13, 50
CLP-M300A	M	1K		13, 50
CLP-Y300A	Y	1K		13, 50
CLP-K350A	BK	4K	Samsung CLP-350/350N (KOR, EXP)	63, 45
CLP-C350A	C	2K		63, 45
CLP-M350A	Y	2K		63, 45
CLP-Y350A	M	2K		63, 45

CLP-K600A	BK	4K	Samsung CLP-600/600N/650(KOR、EXP)	63,45
CLP-C600A	C	4K		63,45
CLP-M600A	Y	4K		63,45
CLP-Y600A	M	4K		63,45
CLP-K610A	BK	5.5K	Samsung CLP-610/660(KOR、EXP) New	63,45
CLP-C610A	C	5K		63,45
CLP-M610A	Y	5K		63,45
CLP-Y610A	M	5K		63,45
Minolta Toner Chips				
9100	BK	#	Minolta 9100	81,00
1710567-003	BK	6K	Minolta PP1300W/1350W/1380/1390 EXP	27,00
9J04204	BK	2K	Minolta PP1400W EXP	27,00
QMS1490	BK	#	Minolta 1480/1490MFP New!!	222,75
QMS1600	CMYK	2.5K	Minolta magicolor1600W/1650EN/1690MF/1680MF	71,55
QMSC200D	CMYK	CMY45K;K6 0K	Minolta Bizhub C200 IU Chip	162,00
QMSC203T	CMYK	CMY19K;K2 4,5K	Minolta Bizhub C203/253 Toner Chip	135,00
QMSC203D	CMYK	CMY75K;K1 00K	Minolta Bizhub C203/253 IU Chip	162,00
QMSC353T	CMYK	CMY20K;K2 6K	Minolta Bizhub C353 Toner chip	135,00
QMSC353D	CMYK	CMY90K;K1 20K	Minolta Bizhub C353 IU chip	162,00
	CMYK	30k	Minolta Bizhub C35 IU chip	567,00
	CMYK	120k	Minolta Bizhub C220 IU Chip	756,00
QMS4650T	CMYK	8K	Minolta magicolor 4650/4690/4695 Toner Chip	135,00
QMS4650	BK	18K	Minolta PagePro 4650/4690/4695 black	148,50
QMS8650T	CMYK	20K	Minolta 8650 Toner Chip	135,00
QMS8650D	CMYK	90K	Minolta 8650 IU Chip	135,00
250T	CMYK	CMY20K;K1 2K	Minolta C250/252/300/352 CMYK	81,00
250D	CMYK	CMY20K;K1 2K	Minolta C250/252/300/352 IU CHIP	81,00
350D	CMYK	CMY80K;K5 0K	Minolta C350/450 CYMK	81,00
550D	CMYK	#	Minolta C550 CYMK	81,00
650D	CMYK	#	Minolta C650 CYMK	108,00
5430	CMYK	#	Minolta 5430 CMYK	81,00
7400T	CMYK	#	Minolta 7400/7440 CMYK	81,00
7400D	CMYK	#	Minolta 7400/7440 IU Chip	81,00
2400W	CMYK	#	Konica Minolta magicolor 2400W/2430DL/2450	27,00
2500W	CMYK	#	Konica Minolta magicolor 2400W/2430DL/2450/2500 original	81,00
1600F		#	Chip card for Minolta 1600F	250,56
1490MF		#	Chip card for Konica Minolta 1490MFP	250,56
Xerox Toner Chips				
FAX2121	BK	6K	Xerox FAX 2121 New	216,00
FAX3100	BK	4K	Xerox FAX 3100 Chip card New	216,00
106R01473-76	CMYK	#	Xerox C6121 New	121,50
106R01245	BK	4K	Xerox Phaser 3428D/3428DN	32,40
106R01246	BK	8K		32,40
113R00730	BK	3K	Xerox 3200mfp	32,40
106R01485/1487/1486	BK	2K/4.1K/5K	Xerox Work Centre 3210/3220 New!	162,00
108R00908/108R00909	BK	1.5K/2.5K	Xerox Paser3140; Phaser3155/3160 Universal New!	162,00
106R01528/106R01530	BK	5K/11K	Xerox WorkCentre 3550 New!	162,00
3250	BK	5K	Xerox 3250	32,40
3300	BK	4K/8K	Xerox 3300	32,40
3425	BK	#	Xroox 3425	32,40
CWAA0762	BK	4K	Xerox P3435	32,40
106R01415	BK	10K		32,40
3600	BK	14K/20K	Xrox 3600	32,40
3635	BK	10K	Xerox 3635	32,40
4118	BK	#	Xerox 4118	32,40
106R01047	BK	8K	Xerox Work Centre M-20/20i	32,40
013R00601	BK	3.5K	Xerox PE120/PE120i	13,50
013R00606	BK	5K		13,50

109R00746	BK	3.5K	Xerox Phaser 3150B	13, 50
109R00747	BK	5K		13, 50
106R00687	BK	5K	Xerox Phaser 3450B	13, 50
106R00688	BK	10K		13, 50
3500	BK	6K	Xerox Phaser 3500	13, 50
3500	BK	12K		13, 50
106R01033	BK	5K	Xerox Phaser 3420	13, 50
106R01034	BK	10K		13, 50
013R00625	BK	3K	Xerox Phaser 3119	13, 50
013R00621	BK	3K	Xerox Work Centre PE220	13, 50
1080	BK	#	Xerox 1080/2000	229, 50
CT350251	BK	10K	Xerox 202/205/255/305 New	121, 50
CT350268	BK	10K	Xerox 240A/340A New	152, 55
CT350269	BK	17K	Xerox 340A New	152, 55
113R00657	BK	18K	Xerox 4500	148, 50
113R00712	BK	19K	Xerox 4510	148, 50
113R00495	BK	20K	Xerox 5400	148, 50
113R00668	BK	#	Xerox 5500 toner chip	144, 45
113R00670	BK	#	Xerox 5500 drum chip	162, 00
2065	BK	#	Xerox 3055/2065	141, 75
518	BK	#	Xerox 518/520	63, 45
415	BK	#	Xerox WC415/420	40, 50
113R00443	BK	10k	Xerox N2050/2825	44, 55
CT350103	BK	10K	Xerox DP180/181/210/211	99, 36
DC230	BK	#	Xerox DC230/235/280/285/405	99, 36
DC240	BK	#	Xerox dc 240/340/440/400	99, 36
DC330	BK	#	Xerox dc330/440/332/4325/425	99, 36
315	BK	#	Xerox 315/320	99, 36
N32	BK	#	Xerox N32	99, 36
N24	BK	#	Xerox N24/42/40	99, 36
113R00196	BK	30K	Xerox N4525	99, 36
831	BK	#	Xerox 831	99, 36
236T	BK	#	Xerox236/286/336/2005/2055/3005-Toner Chip	189, 00
236D	Drum	#	Xerox236/286/336/2005/2055/3005- Drum Chip	189, 00
6100	CMYK	#	Xerox Phaser 6100 (EURO,EXP)	44, 55
106R01274	BK	2K	Xerox Phaser 6110/MFP 6110 (EURO,EXP)	13, 50
106R01271	C	1K		13, 50
106R01272	M	1K		13, 50
106R01273	Y	1K		13, 50
113R00692	BK	8K	Xerox Phaser 6120	81, 00
113R00693	C	4.5K		81, 00
113R00694	M	4.5K		81, 00
113R00695	Y	4.5K		81, 00
106R01338	BK	2K	Xerox Phaser 6125 Middle East Version	27, 00
106R01335	C	1K		27, 00
106R01336	M	1K		27, 00
106R01337	Y	1K		27, 00
106R01334	BK	2K	Xerox Phaser 6125 Euro,North American Version	27, 00
106R01331	C	1K		27, 00
106R01332	M	1K		27, 00
106R01333	Y	1K		27, 00
106R01285	BK	2.5K	Xerox Phaser 6130 Middle East Version	27, 00
106R01282	C	1.9K		27, 00
106R01283	M	1.9K		27, 00
106R01284	Y	1.9K		27, 00
106R01281	BK	2.5K	Xerox Phaser 6130 Euro,North American Version	27, 00
106R01278	C	1.9K		27, 00
106R01279	M	1.9K		27, 00
106R01280	Y	1.9K		27, 00
113R00726	BK	8K	Xerox Phaser 6180	148, 50
113R00719;113R00723	C	6K		148, 50
113R00720;113R00724	M	6K		148, 50
113R00721;113R00725	Y	6K		148, 50

106R01395	BK	7K	Xerox Phaser 6280 New!	198, 45
106R01392	C	5.9K		198, 45
106R01393	M	5.9K		198, 45
106R01394	Y	5.9K		198, 45
106R00672(K)	BK	8K	Xerox Phaser 6250	175, 50
106R00673	C	9K		175, 50
106R00674	M	10K		175, 50
106R00675(Y)	Y	11K		175, 50
106R01082	BK	7K	Xerox Phaser 6300	175, 50
106R01083	C	7K		175, 50
106R01084	M	7K		175, 50
106R01085	Y	7K		175, 50
106R01144	BK	10K	Xerox Phaser 6350	175, 50
106R01145	C	10K		175, 50
106R01146	M	10K		175, 50
106R01147	Y	10K		175, 50
CT201118	BK	2K	Xerox DOCUPRINT C1110/1110B	27, 00
CT201119	C	2K		27, 00
CT201120	M	2K		27, 00
CT201121	Y	2K		27, 00
CT200649	BK	4K	Fuji-Xerox Docuprint C525A/C2090A toner chip	67, 50
CT200650	C	4K		67, 50
CT200651	M	4K		67, 50
CT200652	Y	4K		67, 50
CT350390	Drum	#	Fuji-Xerox Docuprint C525A/C2090A Drum chip	94, 50
CT350504	BK	8K	Xerox C2100/3210	175, 50
CT350505	C	6K		175, 50
CT350507	M	6K		175, 50
CT350506	Y	6K		175, 50
CT200379	BK	15K	Xerox 2428	270, 00
CT200381C	C	12K		270, 00
CT200385M	M	12K		270, 00
CT200383Y	Y	12K		270, 00
C2535	CMYK	8K/ 9K	Xerox C2535	189, 00
C3290	CMYK	6K/ 8K	Xerox C3290	189, 00
6360	CMYK	#	Xerox 6360	158, 76
7400	CMYK	#	Xerox 7400	229, 50
7750D	Drum	#	Xerox 7750 Drum Chip	72, 36
7760D	Drum	35K	Xerox 7760 Drum Chip	108, 00
7760	CMYK	32K/25K	Xerox 7760 Toner Chip EUR	229, 50
Lexmark Toner Chips				
1201/35SE	BK	2K	Lexmark E120/120n(Universal)	27, 00
12S0300/400	BK	2.5K	Lexmark E220/E321/E323/IBM 1312/DELL 1500	27, 00
12A7405	BK	6.5K		27, 00
12A8300/400	BK	2.5K	LexmarkE230/E232/E238/E240/E330/E332/E332n/E340/E342/E342n DELL	27, 00
12A8305/405	BK	6K	1700/1710/1700n/1710n; /IBM 1412/1512	27, 00
X340A1/21G	BK	3K	Lexmark X340N/X342N	27, 00
E250A1/21E	BK	3.5K	Lexmark E250/E350/E352/E352dn (Universal)	32, 40
E352H1/21E	BK	9K	Lexmark E350/E352/E352d/E352dn (Universal)	32, 40
E450H1/21E	BK	11K	Lexmark E450/450dn (Universal)	32, 40
12A73/415	BK	10K	Lexmark T420/420d/DELL S2500 /IBM 1222	32, 40
X422	BK	10.5K	Lexmark x422 /IBM ip 1410	32, 40
X203 New!	BK	2.5K	Lexmark X203/204	54, 00
X264	BK	9K	Lexmark X264/363/364 Toner Cartridge NEW	81, 00
X642	BK	21K\32K	Lexmark X642/X644/X646 Toner Cartridge NEW	81, 00
12A67/835	BK	20K	Lexmark T520/522/IBM IP1120/1125	32, 40
12A67/865	BK	30K	Lexmark T620/622 /IBM IP1130/1140	32, 40
12A73/462	BK	21K	Lexmark T630/632/632n/634/IBM IP1332/1352/1372	32, 40
12A73/465	BK	32K		32, 40
6401/36HE	BK	21K	Lexmark T640/642/645	32, 40
08A0477/8	BK	6K	Lexmark E320/E322	40, 50
12A83/420	BK	6K	Lexmark T430/430d/430dn /IBM1422	40, 50
14K0050	BK	12K	Lexmark W812; IBM1226	108, 00

C522	CMYK	#	Lexmark C520/522/524/530/532/534	270, 00
Epson Toner Chips				
S050167	BK	3K	Epson EPL-6200/6200L	18, 90
S050166	BK	6K	Epson EPL-6200	18, 90
EP1220	BK	#	Epson EPL-1220	32, 40
EP2180	BK	#	Epson EPL-2180	32, 40
EP2120	BK	#	Epson EPL-2120	108, 00
S051090	BK	6K	Epson EPL-N2020 (New)	121, 50
S051091	BK	10K	Epson EPL-N2500 (New)	121, 50
S051111	BK	6/17K	Epson EPL-N3000 (New)	135, 00
M2000	BK	8K	Epson M2000/2010 (New)	81, 00
LP7000	DRUM	30K	Epson C7000/C8000/8200/C8500/8600	44, 55
LP8100	DRUM	10K	Epson 8700/8100	99, 36
LP9100	DRUM	10K	Epson 9100	198, 45
SO50190	BK	4K	Epson C1100/CX11	81, 00
SO50189	C	4K		81, 00
SO50188	Y	4K		81, 00
SO50187	M	4K		81, 00
C1100D	DRUM	#	Epson C1100/CX11 Drum chip	104, 76
SO50146	C	8K	Epson Aculaser 4100 toner chip	158, 76
SO50147	Y	8K		158, 76
SO50148	M	8K		158, 76
SO50149	BK	10K		158, 76
EP-4100	DRUM	#	Epson Aculaser 4100 Drum chip	158, 76
	CMYK	#	Epson Aculaser 1600 (New)	108, 00
EP-4200	CMYK	#	Epson Aculaser C4200 (New)	158, 76
C2600	CMYK	#	Epson Aculaser C2600 (New)	279, 45
C2800	CMYK	#	Epson Aculaser C2800 (New)	180, 36
C3000	CMYK	#	Epson Aculaser C3000 (New)	158, 76
C3800	CMYK	#	Epson Aculaser C3800 (New)	180, 36
CX21N	CMYK	#	Epson Aculaser CX21N (New)	180, 36
DELL Toner Chips				
310-5416	BK	3K	Dell 1600N	13, 50
310-5417	BK	5K		13, 50
DELL1700	BK	3/6K	Dell 1700/1710; LEXMARK E230/330	32, 40
310-8709	BK	3.5K/9K	Dell 1720 ;LEXMARK E250	32, 40
310-7943	BK	3K	Dell 1815	32, 40
310-7945	BK	5K		32, 40
Dell 3000D	DRUM	#	Dell 3000/3010/3100-Drum chip	148, 50
Dell 3000	CMYK	2K	Dell 3000/3010 toner chip	121, 50
Dell 3100	CMYK	4K	Dell 3100 toner chip	121, 50
Dell 3110	CMYK	4K	Dell 3110 toner chip	175, 50
Dell 3115	CMYK	8K	Dell 3110/3115 toner chip	175, 50
Dell 3130	CMYK	9K	Dell 3130 toner chip New!	175, 50
Dell 1230	CMYK	1.5K/1K	Dell1230/1235C New!	157, 95
Dell 1320	CMYK	2K/4K	Dell 1320 toner chip	27, 00
Dell 5100	CMYK	CMY8K;K9	Dell 5100 toner chip /Drum Chip	175, 50
Dell 5110	CMYK	CMY12;K18	Dell 5110 toner chip/Drum Chip	175, 50
Kyocera Toner Chips				
TK-310 Euro	BK	12K	Kyocera FS-2000/FS-2000D	67, 50
TK-312 Euro	BK	12K	Kyocera FS-2000DN	67, 50
TK-320 Euro	BK	15K	Kyocera FS-3900DN	67, 50
TK-322 Euro	BK	15K	Kyocera FS-3900DN	67, 50
TK-332 /330 Euro	BK	20K	Kyocera FS-4000DN	67, 50
TK-440 Euro	BK	15K	Kyocera FS-6950DN	108, 00
TK-130 /132 Euro	BK	7.2K	Kyocera FS-1300D/1300DN	108, 00
TK-140/412/144 Euro	BK	4K	Kyocera FS-1100	108, 00
TK-340 Euro New!!!	BK	12K	Kyocera FS-2020D	108, 00
TK-350 Euro New!!!	BK	15K	Kyocera FS-3920DN	108, 00
TK-360 Euro New!!!	BK	20K	Kyocera FS-4020DN	108, 00
TK-710/712	BK	#	Kyocera FS-9530DN/9130DN	108, 00
TK-675 Euro	BK	34K	Kyocera KM-2540/2560/3060/3040	108, 00

TK-678 Euro	BK	34K	Kyocera KM-2540/2560/3060/3040	108,00
TK-715 Euro	BK	40.8K	Kyocera KM-3050/4050/5050	108,00
TK-718 Euro	BK	40.8K	Kyocera KM-5050	108,00
TK-825K Euro	BK	15K	Kyocera KM-C2520/C2525/C3225/C3232/C4035	108,00
TK-825CMY Euro	CMY	7K		108,00
TK-827K Euro	BK	15K	Kyocera KM-C2520/C2525/C3225/C3232/C4035 K/M/Y/C	108,00
TK-827CMY Euro	CMY	7K		108,00
OKI Toner Chips				
44250724	BK	2.5K	OKI C110/C130/MC160 New!!!	94,50
44250723	C	2.5K	OKI C110/C130/MC160 New!!!	94,50
44250721	Y	2.5K	OKI C110/C130/MC160 New!!!	94,50
44250722	M	2.5K	OKI C110/C130/MC160 New!!!	94,50
3300	CMYK	#	OKI 3300/4400	94,50
2500	BK	4K	OKI B2500/2520/2540 Chip Card	166,86
B4500	BK	3K	OKI B4500/4520/B4525/B4540/B4545	166,86
2200	BK	2K	OKI B2200/2400	99,36
4400	BK	3K	OKI 4400/4600	99,36
B410	BK	10K	OKI B410 / 430 / 440 chip	135,00
52114501	BK	10K	OKI B6200/6300	135,00
52114502	BK	17K	OKI B6300	158,76
52116002	BK	18K	OKI B6500	158,76
5600	CMYK	2/6K	OKI 5600/5700	94,50
5650	CMYK	2/8K	OKI 5650/5750	121,50
5800	CMYK	5/6K	OKI 5500/5800/5900	94,50
5850	CMYK	#	OKI 5850/5950	94,50
8600	CMYK	#	OKI 8600/8800	94,50
9600	CMYK	#	OKI 9600/9800	94,50
Sharp Toner Chips				
Sharp 020	BK	#	SHARP 020	81,00
Sharp AR 151	BK	#	SHARP AR 151	32,40
Sharp AR 160	BK	#	SHARP M160/205	32,40
Sharp AR 163	BK	#	SHARP AR202NT-160/162/163/164/201/205/206/207	32,40
Sharp AR 201	BK	#	SHARP AR 201	32,40
Sharp AR 202	BK	#	SHARP AR 202	32,40
Sharp 158/153	BK	#	SHARP AR158/153/152	32,40
Sharp 203	BK	#	SHARP AR203NT 1818/1820/1828/2818/203/205/2718	32,40
Sharp 208/209	BK	#	SHARP 208/209	32,40
Sharp M350/450	BK	#	SHARP M350/M450/M310U/M420U	32,40
Sharp 351/451	BK	#	SHARP 351/451	32,40
Sharp 550/620/621	BK	#	SHARP M550N/M620N/M700N	32,40
Sharp 271	BK	#	SHARP AR270NT-235/237/271/275/277/255	32,40
Sharp 1818	BK	#	SHARP AR203NT 1818/1820/1828/2818/203/205/2718	32,40
Sharp 016	BK	#	SHARP AR016	32,40
Sharp 276	BK	#	SHARP M276/M236	32,40
Other Printer Types Toner Chips				
CPG402N	BK	20K	CPG Page Master 402N	135,00
Philips Magic 3 Basic	BK	#	Philips fax Magic 3(PPF531(/R);Magic 3 Primo (PPF531(/R),Magic 3 Primo White (PPF532(/R);Magic 3 Primo White (PPF532(/R)Voice (PPF571(/R), Philips Magic 3 Voice	81,00
Philips fax Magic 5	BK	#	Primo (PPF631 R), Philips / Sagem Magic Vox 5 White (PPF632 R), Philips / Sagem Magic 5 Basic Dect (PPF650R, PPF675 R), Philips / Sagem	81,00
Tally 9220	BK	#	Tally 9220	21,60
Toshiba e-Studio 200S	BK	3K	Toshiba e-Studio 200S Series (T-2025)	27,00